

# MR16 Socket Replacement Instructions

## Remodel Housings

- 1. Shut off electrical supply at source.**
- Remove : a) the trim from the pot,  
b) the lamp from the trim,  
c) the lamp from the socket
- Unscrew the two adjustment screws at the bottom of the can and pull the hooks inside of the can.
- Carefully remove the housing from the ceiling and open the junction box.
- Disconnect the three supply wires (Black, White and Green). The housing is now completely uninstalled. **Be careful not to let the housing fall down.**
- Put the housing aside.
- Tape the three supply wires (Black, White and Green) together to prevent connexion errors.
- Disconnect the two socket wires (Blue and Red) from the transformer/converter.
- Remove the socket by pulling it down from the can.
- Introduce the new socket wires in the can, through the BX conductor until the wires penetrates the junction box.
- Connect the blue and red wires of the socket to the free wires of the transformer/converter.
- Reconnect the three supply wires matching the colors together (Black/Black, White/White and Green/Green).
- Close the junction box.
- Slide the housing into position in the ceiling.
- Push the fastening hooks through the lateral openings and fasten the housing with the adjustment screws.
- Insert : a) The lamp in the socket,  
b) The lamp in the trim,  
c) The trim in the can.
- Turn on the electrical supply.

